

Änderung der DHCP-Einstellungen für Modell: GO-RT-N 150 (Hersteller: dlinkgo by D-Link)

1. Verbindung mit dem Router herstellen (über W-LAN oder LAN)


2. Geben Sie in einem beliebigen Browser folgendes ein:

 http://192.168.0.1/

3. Anschließend gelangen Sie auf die Herstellerseite von D-Link und Sie können sich Anmelden


Login mit folgenden Daten (sofern Sie diese nicht geändert haben):

User Name: **admin**
Kennwort: **[leer]**



4. Einstellungen ändern

„Manual Setup“
öffnen



Product Page : GO-RT-N150 Hardware Version : B1 Firmware Version : 2.00

D-Link

GO-RT-N150 // SETUP ADVANCED TOOLS STATUS SUPPORT

EASY SETUP **INTERNET** WIRELESS SETTINGS NETWORK SETTINGS

INTERNET CONNECTION

There are one ways to set up your Internet connection: you can manually configure the connection.

MANUAL INTERNET CONNECTION OPTION

If you would like to configure the Internet settings of your new D-Link Router manually, then click on the button below.

Manual Internet Connection Setup

Helpful Hints...

- If you consider yourself an advanced user and have configured a router before, click **Manual Internet Connection Setup** to input all the settings manually.

WIRELESS

Copyright © 2012-2013 D-Link Corporation. All rights reserved.

Menüpunkt „Internet“ und „Manual Internet Connection Setup“ öffnen

Product Page : GO-RT-N150 Hardware Version : B1 Firmware Version : 2.00

D-Link

GO-RT-N150 // SETUP ADVANCED TOOLS STATUS SUPPORT

EASY SETUP **INTERNET** WIRELESS SETTINGS NETWORK SETTINGS

WAN

Use this section to configure your Internet Connection type. There are several connection types to choose from: Static IP, DHCP and PPPoE. If you are unsure of your connection method, please contact your Internet Service Provider.

Note : If using the PPPoE option, you will need to remove or disable any PPPoE client software on your computers.

Save Settings Don't Save Settings

ACCESS POINT MODE

Use this to disable NAT on the router and turn it into an Access Point.

Enabled Access Point Mode

INTERNET CONNECTION TYPE

Choose the mode to be used by the router to connect to the Internet.

My Internet Connection is : Dynamic IP (DHCP) Static IP **Dynamic IP (DHCP)** PPPoE (Username / Password)

DYNAMIC IP (DHCP) INTERNET CONNECTION

Use this Internet connection type if your Internet Service Provider (ISP) didn't provide you with IP Address information and/or a username and password.

Host Name : dlinkrouter

Primary DNS Server :

Secondary DNS Server :

MTU : 1500

MAC Address :

Clone Your PC's MAC Address

Save Settings Don't Save Settings

Helpful Hints...

- Internet Connection:** When configuring the router to access the Internet, be sure to choose the correct **Internet Connection Type** from the drop down menu. If you are unsure of which option to choose, please contact your **Internet Service Provider (ISP)**.
- Support:** If you are having trouble accessing the Internet through the router, double check any settings you have entered on this page and verify them with your ISP if needed.

WIRELESS

Copyright © 2012-2013 D-Link Corporation. All rights reserved.

„My Internet Connection is“ in Dynamic IP (DHCP) ändern!

Sichern und Speichern.